


## Upright / Slant Top VGM



\* Upright VGM: Barrier starts from top of base and extends to top of the VGM cabinet

\* Slant-Top/Free Standing VGM: Barrier starts 22" from the floor and extends to top of VGM cabinet.